

Aurora Ax Keychain Flashlight

产品说明书 (CN)

产品特征:

- 多种灯源可选, CREE XP-G3 冷白光或 Nichia 219C 中白光
- 260mAh 锂聚合物可充电电池
- Micro USB 充电带充电指示灯, 约 70 分钟即可充满
- 正面电子按键支持单手操作
- 恒流电路, 稳定输出
- 整体符合人体工程学设计, 提供最佳的握持手感
- 双向口袋抱夹和尾部伞绳孔设计提供多种携带方式
- 尾部支持倒立
- IP65 生活防水

产品参数:

材料: A2x: 不锈钢; A3x: 铝合金; A9: 红铜
长度: 57.3mm
直径: 15.6mm
重量: A2x: 35.7g; A3x: 19.5g; A9: 38.9g
包装配件: 1*说明书, 1*不锈钢钥匙环, 1*不锈钢抱夹
1*USB 充电线, 1*手绳, 1*保修卡

操作方式:

1. 照明模式
 - 一键即亮: 按住开关不放, 松开即灭
 - 开机: 双击 (默认进入月光模式)
 - 换挡: 单击循环 月光-低-中-高
 - 关机: 任意档位下长按 0.3 秒;
或者任意档位下工作超过 3 分钟, 单击关机
记忆模式: 工作三分钟后记忆该档位, 下次开机进入记忆档位

2. 爆闪

- 开机:
 - 1) 关机状态下三击
 - 2) 在照明模式下任意档位三击

- 关机: 单击

注: 高亮档和中亮档工作时, 因为产生大量的热, 手电亮度会在 1 分半内降到 100 流明。

充电:

建议收到本产品后首次使用前先将手电充满电!

- 打开位于侧面的充电口, 通过 Micro USB 线接入电源
- 充电指示灯: 充电状态为红色, 充满为蓝色
- 充电时间: 70 分钟
- 截止电压: 2.4V

注: 当电量低时, 充电指示灯会变红提示需充电, 单击可关闭提示。

警告!!

- 当手电筒点亮时, 请勿直视发光体 (LED)
- 请勿将本产品照射人眼或动物眼睛
- 年龄低于 12 岁的小孩未在监护人陪护下禁止使用本产品
- 为了产品可靠性, 筒身与筒头密封, 无法拆卸

质保服务:

- 保修期: 自购买日起 2 年
- 任何明显人为原因造成的功能故障或外观不良不在保修范围内

User Manual (EN)

Features:

- Optional CREE XP-G3 (max 650 lumens) or Nichia 219C (90+ CRI) LED
- Powered by built-in 260mAh Li-po rechargeable battery
- Micro USB rechargeable with charging indicator, fully charged in about 70 minutes
- E-switch supports one-handed operation
- Constant Current board, no PWM
- Ergonomic design provides better grip and hold
- Reversible pocket clip included, and paracord hole at tail
- Tail stand capability
- IP65 weather resistance

Parameters

Material: A3: Aluminum; A2: Stainless steel; A9: Copper

Length: 57.3mm / 2.26"

Diameter: 15.6mm / 0.61"

Weight: A2x: 35.7g / 1.26oz

A3x: 19.5g / 0.69oz; A9: 38.9g / 1.37oz

Accessory: 1*User Manual, 1*SS Key ring, 1*SS Pocket clip, 1*USB Cable, 1*Lanyard, 1*Warranty Card

Operation/User Interface

1. Illumination
 - Momentary ON: Press and hold, release to turn off
 - Turn ON: Double click (default from moonlight)
 - Switch mode: click to cycle thru Moonlight-Low-Med-High
 - Turn Off:
 - 1) At any mode, long press the button 0.3s;
 - 2) Click to turn off when the light works at any mode over 3mins.**Memory:** When the light worked at a mode over 3mins, it will be turned on from the memorized mode next time.

2. Strobe (Emergency mode)

- Turn ON
 - a) From off, triple click
 - b) From any mode of Illumination, triple click
- Turn Off: Click

Note: When the light is working at High mode or Medium mode, it will step down to 100 lumens in 90 seconds due to the massive heat generated.

Charging:

Highly recommend charging the light before the first use.

- Open the USB port cover and connect to a power source thru Micro USB cable
- Charging indicator: Red is in charging, Blue is fully charged.
- Charging time: 70 minutes
- Cutoff voltage: 2.4V

Note: If the battery is low, the indicator will come on Red to remind recharging, click the button to turn the indicator off.

Warning!!

- DO NOT look directly into the emitter when it's ON
- DO NOT point the light at human eyes or animal eyes
- Child under 12 years old is NOT permitted to use the light unsupervised.
- The flashlight was glue sealed for the reliability, and disassembly is not under warranty.

Warranty:

- 2 years international manufacturer warranty
- Any human-made malfunction or defective is out of warranty.